

	AMBASSADOR CLASSIC	AMBASSADOR SQUARE	HORIZON CLASSIC	HORIZON SQUARE	PRISM	MORPHEUS	SHERATON	GEORGIAN	VICTORIAN	TRUE EDGE	SMOOTHIE
POWER											
UNSWITCHED SOCKET OUTLETS											
TWIN 10 AMP 2 PIN			•		•						
10 AMP 3 PIN			•		•						
10 AMP 5 PIN			•		•						
10 AMP 5 PIN + 2 USB'S			•		•						
16 AMP 3 PIN			•		•						
16 AMP CARD SWITCH			•		•						
SHAVER SOCKETS											
SHAVER SOCKET OUTLET 110•240 VOLTAGE			•		•						
LIGHTING											
ROCKER GRID SWITCHES (Metal Switches)											
1 GANG 20 AMP 2 WAY SWITCH			•		•						
1 GANG 20 AMP DOUBLE POLE SWITCH			•		•						
1 GANG 20 AMP INTERMEDIATE SWITCH			•		•						
1 GANG 20 AMP 2 WAY AND OFF SWITCH			•		•						
1 GANG 20 AMP RETRACTIVE SWITCH			•		•						
1 GANG 20 AMP 2 WAY AND OFF RETRACTIVE SWITCH			•		•						
2 GANG 20 AMP 2 WAY SWITCH			•		•						
3 GANG 20 AMP 2 WAY SWITCH			•		•						
4 GANG 20 AMP 2 WAY SWITCH			•		•						
ROCKER GRID SWITCHES (Plastic Switches)											
1 GANG 20 AMP 2 WAY SWITCH			•		•						
1 GANG 20 AMP DOUBLE POLE SWITCH			•		•						
1 GANG 20 AMP INTERMEDIATE SWITCH			•		•						
1 GANG 20 AMP 2 WAY AND OFF SWITCH			•		•						
1 GANG 20 AMP RETRACTIVE SWITCH			•		•						
1 GANG 20 AMP 2 WAY AND OFF RETRACTIVE SWITCH			•		•						
2 GANG 20 AMP 2 WAY SWITCH			•		•						
3 GANG 20 AMP 2 WAY SWITCH			•		•						
4 GANG 20 AMP 2 WAY SWITCH			•		•						
TOGGLE GRID SWITCHES											
1 GANG 20 AMP 2 WAY TOGGLE SWITCH			•		•						
1 GANG 20 AMP DOUBLE POLE TOGGLE SWITCH			•		•						
1 GANG 20 AMP INTERMEDIATE TOGGLE SWITCH			•		•						
1 GANG 20 AMP 2 WAY AND OFF SWITCH			•		•						
2 GANG 20 AMP 2 WAY TOGGLE SWITCH			•		•						
3 GANG 20 AMP 2 WAY TOGGLE SWITCH			•		•						
4 GANG 20 AMP 2 WAY TOGGLE SWITCH			•		•						

	AMBASSADOR CLASSIC	AMBASSADOR SQUARE	HORIZON CLASSIC	HORIZON SQUARE	PRISM	MORPHEUS	SHERATON	GEORGIAN	VICTORIAN	TRUE EDGE	SMOOTHIE
AV & DATA											
TELEVISION OUTLETS											
1 GANG CO/AXIAL T.V.			•		•						
2 GANG CO/AXIAL T.V.			•		•						
1 GANG SATELLITE SOCKET OUTLET			•		•						
TV/SATELLITE SOCKET			•		•						
TV/FM/SAT TRIPLEX OUTLET			•		•						
TV/FM/SAT/SAT QUADPLEX OUTLET			•		•						
TELEPHONE • DATA OUTLETS											
1 GANG BT MASTER			•		•						
2 GANG BT MASTER			•		•						
1 GANG BT SLAVE			•		•						
2 GANG BT SLAVE			•		•						
1 GANG RJ45 CAT 5•6			•		•						
2 GANG RJ45 CAT 5•6			•		•						
SPEAKER SOCKETS											
1 GANG SPEAKER SOCKET			•		•						
2 GANG SPEAKER SOCKET			•		•						
BRUSH PLATES			•		•						
2 MODULE BRUSH PLATE			•		•						
4 MODULE BRUSH PLATE			•		•						
BLANK PLATES											
SINGLE BLANK PLATE			•		•						
TWIN BLANK PLATE			•		•						
EURO MODULE PLATES			•		•						
1 MODULE EURO PLATE			•		•						
2 MODULE EURO PLATE			•		•						
3 MODULE EURO PLATE			•		•						
4 MODULE EURO PLATE			•		•						